

TEL'740-5062860




FIGURE 1






FIGURE 2

TO CZ 10: 5002260








Figure 5



POWER CONTROL MESSAGE



C[1:0] denote channel band (low, mid, or high)  
 P[2:0] denote power level (0 through 7)




FIGURE 7

PROZ 40-5062260




FIGURE 8